

Ancestral Apparition

What makes this so special is the unique blending of the reverb with an ADDED DELAY! This just makes the shimmering reverb effect even more powerful! Advance the ATTACK control to add in just the right amount of DELAY! Use the DECAY control to add some feedback for even more expansiveness! Finally, turn up that DEPTH control to sink your instrument deep into the cavern! Now you've added that ambiance and expansiveness that's been missing!

Add just a small amount or go huge for dramatic emphasis! It's all up to you!





Part	Value	Part	Value	Part	Value	Part	Value
R1	1k8	R12	10k	C1	100u	C12	100n
R2	10k	R13	100k	C2	100u	C13	100n
R3	10k	R14	10k	C3	10 u	C14	100n
R4	1M	R15	15k	C4	220n	C15	1n
R5	1M	R16	15k	C5	470n	C16	100n
R6	10k	R17	10k	C6	470n	C17	10n
R7	22k*	R18	15k	C7	2u2	C18	2n2
R8	12k	R19	1k	C8	1u	C19	470n
R9	22k	R20	33k	C9	100n	C20	10 u
R10	18k**	R21	22k	C10	100 u		
R11	470R	R22	10k	C11	10 u	BTDR-2H	LONG

Part	Value					
D1	CA Status LED					
D2	1N4001					
IC1	PT2399					
IC2	TL074					
IC3	78L05					
IC4	78L05					
DECAY	B5k					
DEPTH	B2k					
ATTACK	B10k					


Build Notes:

Reverb Bricks: Amplified Parts, Small Bear or in Europe see Das Musikding

*R7 stock is 22k. If you would like to add even more Decay you can try using anything from 8k to 10k here.


Please note that Mods are not included with Kits.

**R18 Please note updated value for R10, now 18k to provide unity gain. Original value (10k) made the circuit quieter than unity.




Note: If wiring the LED to our 3PDT board no need to connect S4, S5 & S6 or populate D1 or R1 (CLR) on the main board since you are wiring your LED directly to our board.

Note: If wiring the LED to our 3PDT board no need to connect S4, S5 & S6 or populate D1 or R1 (CLR) on the main board since you are wiring your LED directly to our board.





Potentiometers. Drill Tips: Measure your components before selecting a drill bit. We recommend drilling the pot holes, mounting the pots in the enclosure, and then soldering the pots to the board. This approach should resolve the issue of the pots not fitting through the holes after soldering. We also recommend you make the holes for the pots a little larger than the threads in case you decide to remove the board and put it back in during the build, to avoid problems. Use this guide at your own risk. Make sure page scaling is turned off when you print this PDF, or the image above may be smaller than expected. <u>Verify everything before drilling.</u>







GuitarPCB Tip Sheet











Multiple +9v and Ground Pads are convenient hookup points for additional circuits within the same enclosure. This also allows for diverse wiring schemes to suit indiviual needs.





Input/Output Jack Wiring T = Tip | R = Ring | S = Sleeve

A Stereo Jack is only needed if using a Battery. Otherwise use a Mono Jack Battery Strap RED wire is connected to Power Jack Battery Strap Black wire is connected to RING (stereo jack) If wiring an LED to our 3PDT Wiring Board then S4, S5 & S6 are not needed

